

Item Number	Document Number	Title	Quantity	Item Number	Document Number	Title	Quantity	Item Number	Document Number	Title	Quantity	Item Number	Document Number	Title	Quantity	Item Number	Document Number	Title	Quantity	Item Number	Document Number	Title	Quantity	Item Number	Document Number	Title	Quantity	Item Number	Document Number	Title	Quantity	Item Number	Document Number	Title	Quantity			
1	HS-950-D	Table	1	10	HS-125-A	H / Lo Speed Decal	1	19	HS-243-A	Table Tilt Pinion	1	28	HS-434-A	T-Bolt - Short	1	37	HS-644-A	Coupling Pin	1	46	GS-2236-A	T Single Price Saw Guide	2	55	HS-547-A	Clamp Pin Nut	1	64	5100-75	External Retaining Ring	1	73	Stop Button	CH 10250130R	1	82	Work Light - Short	1
2	HS-932-A	Decal - Shift Positions	1	11	HS-505-D	Frame	1	20	HS-965-A	Table Tilt Stop	1	29	HS-281-C	Table Tilt Scale	1	47	HS-1068-A	Wagon Box Head Pin	1	56	S-547-A	Guide Holder Clamp Stud	2	65	5100-75	External Retaining Ring	1	74	Start Button	CH 10250130B	1	83	HS-941-B	Upper Saw Band Guard	1			
3	HS-745-C	Air / Hydraulic Feed Assy	1	12		8" Grob Decal	1	21	HS-441-A	Table Filter Plate (Front)	1	30	HS-610-A	Table Tilt Warning	1	48	HS-587-A	Guide Bar Clamp Pin	2	57	HS-562-A	Tension Pickup Cover	1	66	HS-850-A	40 Tooth Sprocket	1	75	GS-2286-B	Built Wider Blank Plate	1	84	Work Light - Long	1				
4	HS-348-A	3/4" Set Collar	1	13		Sawing Chart	1	22	HS-439-A	Table Filter Plate (Rear)	1	31	HS-106-B	Outer Table Support Bracket	1	49	HS-323-A	Clamp Pin	2	58	HS-560-A	Chain Adjustment Cover	1	67	5100-112	External Retaining Ring	2	76	HS-273-B	Air Gauge & Valve Assy	1	85	HS-435-A	T-Bolt - Long	2			
5	F-319-A	3/4" Flanged Bushing	4	14		DMG2R Plate	1	23	HS-107-B	5/16" B Wing Nut	1	32	HS-966-B	Lower Saw Band Guard	1	50	HS-324-A	Guide Bar Clamp	1	59	HS-610-C	Front Roller Assembly	1	68	HS-442-A	Tension Crank Pin	1	77	HS-933-A	Speed Chart Plate	1	86	HS-1000-A	HS Lower Base Pin	2			
6	HS-303-B	Table Tilt Crank Assembly	1	15	HS-309-C	Rear Saw Band Guard	1	24	HS-963-A	Table Filter Plate (Rear)	1	33	HS-107-C	Inner Table Support Bracket	2	42	HS-521-A	Lower Guide Bar	1	40	HS-1037-D	Power Unit Assembly	1	69	HS-310-A	Stop Miter for Shifting Decal	1	78	HS-931-B	Speed Chart	1	87	HS-1520-B	Surge Tank	1			
7	HS-954-B	Rear Base Cover	1	16	HS-1074-A	Rear Saw Band Stud	4	25	HS-426-B	Table Tilt Crank Support	1	34	HS-437-A	Table Index Painter	1	43	HS-241-B	Table Tilt Shaft Clamp	1	52	HS-633-C	Sub Base	1	70	HS-231-A	Caution Close Door Decal	1	79	HS-285-A	Door Limit Switch Assy	2	88	HS-1075-D	Air Line - Reg	1			
8	HS-1076-C	Electrical Box Assembly	1	17	HS-125-C	Base Door Assembly	1	26	HS-288-A	Bar Release Decal	1	35	HS-1232	Idle Bearing	2	44	HS-589-A	R Table Support Bk1	1	53	HS-552-A	Clamp Stud	1	62	HS-548-A	Switch Box Cover	1	80	HS-2911-C	Saw Pulley	2	89	HS-978-B	Front Base Cover	1			
9	HS-593-A	Crank Assembly	2	18	HS-244-C	Gear Sector	2	27	HS-297-A	Table Tilt Pinion	1	36	HS-297-A	Table Tilt Pinion	1	45	S-1124-A	S/6-1 Upper 1 Pc Guide Holder	2	54	HS-546-A	Handle for Clamp Pin Nut	1	63	HS-578-A	Tension Crank Shaft	1	72	AR 800T-D402	Emergency Stop Button	1	81						

