


Instructions for Installing Grinder Motor in Grob RWA Butt Welder



To Remove Welder From Machine, Disconnect Two Line Wires and One Ground From Switch Box

